

Tester for ionizing equipment **ECO-TEST**

Tester for ionizing equipment ECO-TEST

On your machines, you will have features for eliminating electrostatic charges, bars, blowers, guns, etc. You will want to ensure that your systems are in perfect working order.

How to use:

Before use connect the ECO-TEST to the earth.

In order to this, insert the cable in the earth plug of the ECO-TEST and to the earth of the machine or material using a crocodile clip. You can now carry out the test.

- a) Switch on the material to be tested.
- b) Put the touch point of the ECO-TEST on one of the points and wait a few seconds.

1st example: the neon light located at the edge of the ECO-TEST flashes at intervals = your device is in perfect working order.

2nd example: the neon light located at the edge of the ECO-TEST does not come on at all = your material is not working properly.

Please note:

The frequency at which the neon light is lit will vary depending on the active part of the bar.





